

01 - 10 ENGINE KITS












Diagram 11: Crankshaft and main bearings.

Diagram 10: Main bearings and other components.

144618 350	144619	144621	144844
144643 500	144622 (350)	144628 (500, 535)	144846 (2 Nos)
144047	144620 (2 Nos)	144616 (2 Nos)	144844 (2 Nos)
	144625	140593 (4 Nos)	144633
	110009 (350) 12471	140771 (10 Nos)	140027
	144617 (500, 535)		140098
			140097
			140297 (2 Nos)

