


05 - 20 GEAR BOX END COVER



A1
Key Nos
3,4

A
Key Nos
6,7,8,9,10

A3
Key Nos
36, 37, 38, 39, 40

05 - 20 GEAR BOX END COVER

Key No	Part Numbers		Description	Qty	Models										Remarks	price
					350cc				500cc							
	K.Start 4 Speed				E.Start 4 Speed		K.Start 4 Speed		E.Start 4 Speed		5 Speed		Sixty 5			
	R/G	L/G			R/G	L/G	R/G	L/G	R/G	L/G	K.start	E.start	E.start			
New	Old															
A1	111109		Adjuster Plate Assembly	1	•	•	•	•	•	•	•	•				1,590
A2	111114		Ratchet Outer Assembly	1	•	•	•	•	•	•	•	•				3,890
A3	111152		Spindle Assembly, Foot starter	1	•	•	•	•	•	•	•	•				15,620
1	144454		End Cover, Gear box	1	•		•		•		•					26,730
	113032		End Cover, Gear box	1		•		•		•		•				24,910
2	140755		Spring, Foot Control Lever	1	•	•	•	•	•	•	•					1,400
3	111108		Adjuster Plate, Foot Control	1	•	•	•	•	•	•	•	•				1,230
4	111110		Pin, Spring stop	1	•	•	•	•	•	•	•	•				230
5	111113		Spring, Ratchet	1	•	•	•	•	•	•	•					1,400
6	111119		Pin, Ratchet Operating	1	•	•	•	•	•	•	•	•				270
7	111117		Pin, Spring stop	1	•	•	•	•	•	•	•	•				230
8	111116		Plate, Foot Control	1	•	•	•	•	•	•	•	•				770
9	111115		Ratchet Outer	1	•	•	•	•	•	•	•	•				2,120
10	111118		Bush	2	•	•	•	•	•	•	•	•				180
11	110253		Ratchet Inner	1	•	•	•	•	•	•	•	•				2,660
12	142257		Stop Plate, Pawl	1	•	•	•	•	•	•	•	•				880
13	111120		Stop Plate, Foot Control	1	•	•	•	•	•	•	•	•				660
14	150209		Washer	2	•	•	•	•	•	•	•	•				50
15	140369		Nut	2	•	•	•	•	•	•	•	•				180
16	111159		Pin, Adjuster Plate	2	•	•	•	•	•	•	•	•				430
17	110263		Foot Control Lever, Short	1	•		•		•		•					5,250
	113042		Foot Control Lever, Short	1		•		•		•		•				5,120
18	111102		Bolt, Bearing Cap	1	•	•	•	•	•	•	•	•				180
19	140083		Washer	1	•	•	•	•	•	•	•	•				50
20	111103		Bolt, Bearing Cap	1	•	•	•	•	•	•	•	•				180
21	145148/A	111168	Cap, Ball Bearing	1	•	•	•	•	•	•	•	•				1,050
22	111093		Nut, LH Thread	1	•	•	•	•	•	•	•	•				300

05 - 20 GEAR BOX END COVER

Key No	Part Numbers		Description	Qty	Models										Remarks	price
					350cc				500cc							
	K.Start 4 Speed				E.Start 4 Speed		K.Start 4 Speed		E.Start 4 Speed		5 Speed		Sixty 5			
	R/G	L/G			R/G	L/G	R/G	L/G	R/G	L/G	K.start	E.start	E.start			
23	111092		Lock Washer	1	•	•	•	•	•	•	•	•				410
24	111072		Oil Thrower, Outer	1	•	•	•	•	•	•	•	•				1,080
25	111166		Ball Bearing 6303, Main Shaft	1	•	•	•	•	•	•	•	•				1,640
26	140324		Spring, Kick starter	1	•	•	•	•	•	•	•					2,800
27	111054		Screw, Short	3	•		•		•		•					340
	113037		Screw, Short	3		•		•		•		•				450
28	111053		Screw, Long	2	•	•	•	•	•	•	•	•				390
29	144845	144601	Copper Washer	2	•	•	•	•	•	•	•	•				220
30	145235/A		Plug	2	•	•	•	•	•	•	•	•				560
31	143135		Bolt - stop Plate - F S Pawl	1	•	•	•	•	•	•	•	•				410
32	145234/A		Plug, Filler	1	•	•	•	•	•	•	•	•				610
33	144846		Copper Washer-Oil Filler Plug	1	•	•	•	•	•	•	•	•				270
34	112027		Bush, Foot Operating Shaft	3	•	•	•	•	•	•	•	•				750
35	111171		Foot Operating Lever	1	•		•		•		•					2,910
	113038		Foot Operating Lever	1		•		•		•		•				2,730
36	140332		Plunger, Pawl	1	•	•	•	•	•	•	•	•				930
37	140331		Spring, Plunger	1	•	•	•	•	•	•	•	•				160
38	140333/B	140333	Pawl (Sintered)	1	•	•	•	•	•	•	•	•			From I B511 51 3H	1,320
39	112029		Bush, Lay Shaft	1	•	•	•	•	•	•	•	•				930
40	140337		Spindle, Foot starter	1	•	•	•	•	•	•	•	•				13,140
41	140338		'O' Ring	1	•	•	•	•	•	•	•	•				360
42	143078		Aluminium Washer	5	•		•		•		•					50
	113043		Aluminium Washer	5		•		•		•		•				720