


05 - 30 FOOT CONTROL

A1
Key Nos
19 to 24



05 - 30 FOOT CONTROL

Key No	Part Numbers		Description	Qty	Models										Remarks	price
					350cc				500cc							
	K.Start 4 Speed				E.Start 4 Speed		K.Start 4 Speed		E.Start 4 Speed		5 Speed		Sixty 5			
	R/G	L/G			R/G	L/G	R/G	L/G	R/G	L/G	K.start	E.start	E.start			
New	Old															
A1	112024		Kick starter Lever Assembly	1	•	•	•	•	•	•	•	•				14,700
1	111122		Foot Control Cover Assembly	1	•		•		•		•					13,100
	113040		Foot Control Cover Assembly	1		•		•		•		•				16,060
2	111054		Screw, Short	2	•	•	•	•	•	•	•	•				340
3	111132		Screw, Long	2	•	•	•	•	•	•	•	•				520
4	111128		Inspection Cap	2	•	•	•	•	•	•	•	•				300
5	142282		Screw	2	•	•	•	•	•	•	•	•				270
6	110255		Neutral Lever	1	•	•	•	•	•	•	•	•				4,630
7	111196		Washer	1	•	•	•	•	•	•	•	•				410
8	111129		Screw	1	•	•	•	•	•	•	•	•				230
9	111107		Bush, Eccentric	1	•	•	•	•	•	•	•	•				300
10	111103		Screw	1	•	•	•	•	•	•	•	•				180
11	145248/A	111104	Gear Indicator	1	•		•		•		•					2,540
	113041		Gear Indicator	1		•		•		•		•				2,880
12	110258		Washer, Neutral Lever	1	•	•	•	•	•	•	•	•				270
13	110256		Spring, Neutral Lever	1	•	•	•	•	•	•	•	•				360
14	110257		Spring Cap	1	•	•	•	•	•	•	•	•				410
15	111105		Bolt	1	•	•	•	•	•	•	•	•				680
16	143745		Foot Change Lever Assembly	1	•		•		•		•					6,720
	113073		Foot Change Lever Assembly	1		•		•		•		•				9,770
17	142291		Bolt	1	•		•		•		•					570
	113086		Bolt	1		•		•		•		•				270
18	110203		Rubber Sleeve, Gear Lever	1	•	•	•	•	•	•	•	•				430
	145158/B	145158/A	Rubber Sleeve, Gear Lever	1	•	•	•	•	•	•	•	•			From I B 581 638 A	430
19	112024		Kick starter Crank	1	•	•	•	•	•	•	•	•				
20	151592		Spring	1	•	•	•	•	•	•	•	•				
21	140201		Ball 1/4"	1	•	•	•	•	•	•	•	•				50

05 - 30 FOOT CONTROL

A1
Key Nos
19 to 24

